

“CENTRAL PARK” GOLF BENCH

Installation Instructions

Parts List: (Quantity for one 4' Bench)

- 6 Bench Slats: The front and top slats have four anchor holes!
- 2 Bench Supports
- 16 ¼ x 3 ½ Stainless Steel Lag Screw
- 16 Stainless Steel Washer

Tools Needed for Installation:

Socket Set with a 7/16” Socket

Installation Instructions:

1. Check Parts list to verify all items.
2. Place Washers on the Stainless Steel Lag Screws and start them in the pilot holes (on the Bench Slats).
3. Run the Lag Screws through the pilot holes in the Bench Slats letting them extend through approximately 1/8”.
4. Place the Bench Slats on the Bench Supports and line up the pre drilled holes in the Bench Supports. Start with one on the front and then one on the top (to allow you to get the bench “square.”) Finish with the remaining bench supports in any order.
5. Using the 7/16” Socket tighten the Lag Screws securing the Bench Slats and Bench Supports.

***** IMPORTANT *****

DO NOT TO OVERTIGHTEN THE LAG SCREWS! THIS MAY CAUSE THE PLASTIC BENCH SUPPORTS TO STRIP OUT.

“CENTRAL PARK” BENCH

Installation Instructions

Parts List: (Quantity for one 6’ Bench)

- 6 Bench Slats: All slats are identical and have 5 anchor holes.
- 3 Bench Supports
- 24 ¼ x 3 ½ Stainless Steel Lag Screw
- 24 Stainless Steel Washer

Tools Needed for Installation:

Socket Set with a 7/16” Socket

Installation Instructions:

1. Check Parts list to verify all items.
2. **The bench supports have been matched and banded together in “sets.” Keep them together when assembling the bench slats! The middle support is drilled differently than the two end supports.**
3. Place Washers on the Stainless Steel Lag Screws and start them in the pilot holes (on the Bench Slats).
4. Run the Lag Screws through the pilot holes in the Bench Slats letting them extend through approximately 1/8”.
5. Place the Bench Slats on the Bench Supports and line up the pre drilled holes in the Bench Supports. Start with one on the front and then one on the top (to allow you to get the bench “square.”) Finish with the remaining bench supports in any order.
6. Using the 7/16” Socket tighten the Lag Screws securing the Bench Slats and Bench Supports.

***** IMPORTANT *****

DO NOT TO OVERTIGHTEN THE LAG SCREWS! THIS MAY CAUSE THE PLASTIC BENCH SUPPORTS TO STRIP OUT.

“CENTRAL PARK” BENCH

Installation Instructions

Parts List: (Quantity for one 8' Bench)

- 6 Bench Slats: The front and top slats have eight anchor holes!
- 4 Bench Supports
- 32 ¼ x 3 ½ Stainless Steel Lag Screw
- 32 Stainless Steel Washer

Tools Needed for Installation:

Socket Set with a 7/16” Socket

Installation Instructions:

1. Check Parts list to verify all items.
2. **The bench supports have been matched and banded together in “sets.” Keep them together when assembling the bench slats!**
3. Place Washers on the Stainless Steel Lag Screws and start them in the pilot holes (on the Bench Slats).
4. Run the Lag Screws through the pilot holes in the Bench Slats letting them extend through approximately 1/8”.
5. Place the Bench Slats on the Bench Supports and line up the pre drilled holes in the Bench Supports. Start with one on the front and then one on the top (to allow you to get the bench “square.”) Finish with the remaining bench supports in any order.
6. Using the 7/16” Socket tighten the Lag Screws securing the Bench Slats and Bench Supports.

***** IMPORTANT *****

DO NOT TO OVERTIGHTEN THE LAG SCREWS! THIS MAY CAUSE THE PLASTIC BENCH SUPPORTS TO STRIP OUT.