

Recycled POLY-WOOD

Inc.

ASSEMBLY INSTRUCTIONS MODEL GB-60 & GB-72

STEP 1

ATTACH THE SEAT TO THE SIDEFRAE USING QTY. 4 $\frac{1}{4}$ "-20X2 $\frac{1}{2}$ " BOLTS, WASHERS AND NUTS IN PREDRILLED HOLES (B)

* DO NOT TIGHTEN.

STEP 2

SCREW THE BACK TO THE SIDEFRAES AND INSTALL ADDITIONAL SCREWS IN SEAT USING QTY. 4 IN EACH, #10X3 PAINTED SCREWS IN PRE-DRILLED HOLES (A)


STEP 3

FROM THE BOTTOM, SCREW A $\frac{1}{4}$ "X 5" LAG (D) WITH FENDER WASHER (E) TO THE CENTER SUPPORT OF OF THE BACK ASSEMBLY.

STEP 4

ATTACH THE CENTER LEGS TO THE SEAT USING QTY. 2 $\frac{1}{4}$ "X 3" LAG BOLTS AND WASHERS IN PRE-DRILLED HOLES (C)

* TIGHTEN ALL SCREWS AT THIS TIME. ASSEMBLY IS NOW COMPLETE.



| LETTER | QTY. | DESCRIPTION |
|--------|------|--|
| A | 8 | #10X3" PAINTED SCREW |
| B | 4 | $\frac{1}{4}$ -20 x 2 $\frac{1}{2}$ " TRUSS BOLT |
| B,C | 6 | $\frac{1}{4}$ " FLAT WASHER |
| B | 4 | $\frac{1}{4}$ -20 LOCK NUT |
| C | 2 | $\frac{1}{4}$ " x 3 LAG |
| D | 1 | $\frac{1}{4}$ " x 5 LAG |
| E | 1 | $\frac{1}{4}$ " FENDER WASHER |

TOOLS NEEDED
 PHILLIPS HEAD SCREWDRIVER
 (A SCREW GUN IS RECOMMENDED)
 $\frac{7}{16}$ SOCKET DRIVER